

## **INSTAALLATION OF TC 500 STB**

- 1. Lay the vinyl over the convertible top for protection.**
- 2. Install one cover by holding it up in front at 45 degree and slide the lip at the rear of the cover under the factory black molding on car.**
- 3. Carefully lower the cover, the cover will fit inside of black molding then install second half in same manner.**
- 4. Attach the provided bolts with plastic knobs at the first hole and third hole. Tighten the bolts to keep the pieces together.**
- 5. Lift the cover at the corner by about 10", pull the bungee cord down and hook it to the convertible arm inside the boot. Lower the cover and now pull the bungee cord to the center of the cover and hook it to the second hole. Same for second cover.**
- 6. Install the center piece over the bolts inside the covers and attach the plastic knobs.**